

817 escort ESB/ESG

PORTABLE ZERO LLC
26045 Birch Bluff Road
Shorewood, MN 55331
Email: info@portablezero.com
www.portablezero.com

Assembly:

Parts list: escort side frames side (A) and (B), 1 stand (C), 8 m2.5 x 8 mm screws for side frames (D) *Allen wrench included*, 2 m3 x 12 mm screws for stand (E) *Allen wrench included*. 2 nylon washers for stand(F), 2 steel washers for stand (G) 2 m3 locknuts for stand (H), 2 trigger snaps for strap (I).

Please read the entire instructions before starting installation.

Step 1: Remove your strap from the 817ND transceiver (if attached).

Step 2: Set your transceiver on a soft surface and remove the 4 screws and metal strap attachment tabs from each side.

Step 3: Place your transceiver on a soft surface with its side facing up **per figure 1** and place **side frame (A)** against the 817ND with the stand mount aiming down. Install 4 screws **(C) per figure 1**. Start all screws but leave them loose to make stand installation easier. Note: The side frames can be installed in any order.

Step 4: Install the other **side frame (B)** in the same manner as you just did with **side frame (A)** leaving the screws loose.

Step 5: Stand Installation. Install the stand aiming in the proper direction per **figure 2** and hardware placement per **figure 3** making sure to install the nylon washer between the stand and escort **side frames** and the steel washer on the inside next to the locknut. It will take a little finesse to get the nylon washer to stay in place while installing the stand screw. It works best to slide the screw so it slightly protrudes through the **side frame** and place the nylon washer on the end of the screw, then put the stand in place then push the screw fully into place. Slide on the steel washer and attach the lock nut. Note: Extra nylon washers are included.

Note: If you have problem putting the nylon washers in place, An alternative method is to attach the stand to the **side frames A** and **B** first before installing the side frames on the 817ND.

When the stand is installed, tighten the lock nut with just enough tension to allow the stand to have some resistance when tilted. Some future re-tightening may be necessary.

Step 6: Tighten all 8 screws **D**. Set your 817 transceiver on a flat surface and make sure it is sitting square. If a slight rocking is felt, loosen screws **D** and allow the side frames to square themselves then re-tighten screws. **Caution: Do not over tighten the mounting screws. Just moderate tightening is required. The tapped holes in the radio can be stripped if over tightened.**

Note: slight pressure may be necessary to press the radio top and bottom halves together at the rear before tightening the screws (D)

Step 7: Trigger snap clip installation.

Slide the trigger snaps onto the strap and thread the strap back into the retainer slides in the same manner that the original strap tabs were attached to the strap. Adjust the length as desired. Your strap can now be easily attached or removed from the 817 escort using the front or rear mounting points.

(Place the removed screws and strap tabs in the small resalable parts bag for safe keeping).

Figure 1




Figure 2




Figure 3

